



	s1	s2	s3	s4	s5	s6	
118	10'						317
116	119	218	219	318	320		315
114	115	214	215	314	316		313
112	10'						311
110	111	212	213	312	314		309
108	109	208	209	308	310		307
106	10'						305
104	105	204	205	304	306		303
102	101	200	201	300	302		301

ENTRANCE

ARCHWAY